

How do I set my Navigator icons back to the default images?

- WinSPC's Navigator button icons are customizable for the first 5 buttons.
By default, these buttons are
SPC Setup Inspection Blueprint Instructions

If you change the default icons to other images, but wish to restore them to their default icons, WinSPC 9 and Above:

In WinSPC 9 and above, you can reset the icons by doing the following:

1. Log into WinSPC as a user with Administrative rights
2. Browse to 'Tools' > 'Navigator Setup...'
3. Click on one of the 5 configurable buttons listed above.
4. Click on the Default button next to 'Picture:'

Legacy WinSPC Versions:

In older versions of WinSPC, if you want to restore an original icon after it has been changed, you will need to download the icon set from the 'Attachments' section below.

<https://knowledgebase.winspc.com/questions/221/>