

DataNet Quality Systems Knowledgebase

What is the default login and password for QualTrend?

After a new install of QualTrend, the default login credentials are:

Username: Admin

Password: Admin

The password is case sensitive, note the capital 'A' in the password.

<https://knowledgebase.winspc.com/questions/230/>